

Install Centre Fixed Handles - Back to Back

These instructions are suited to the following back to back sets with a centre fitting:

- All round handles
- Half moon handles

Fittings

Joinery & door handles are supplied with all fittings required for fixing the handles to the door. Included in this set are:

- Metal threaded insert prefixed in rear of each handle
- 1 x threaded rod

Safety

- Always follow the manufacturer's safety instructions when using power tools and adhesives
- Wear safety glasses throughout the installation

Step 1: Set up

You will need

- 4-12mm drill depending upon the size of the fitting
- Safety glasses
- Handle set and fittings

Step 2: Prepare the door

- a) Locate and mark the position for the handles on the door
- b) Drill 4-12mm holes through door at the point marked out above

Step 3: Prepare the handle fitting

Select one handle and wind the threaded rod into the metal insert at the rear of the handle. Wind in fully (not tight) then unwind to bring back approx 5mm.

Step 4: Install

- a) Insert the other end of the threaded rod through the predrilled hole in the door.
- b) On the other side of the door wind the second handle onto the thread and tighten.



All Done!