

Install Centre Fixed Handles - Single sided

These instructions are suited to any handle with a centre fitting (excluding concealed fitting).

Fitting

Joinery & door handles are supplied with all fittings required for fixing the handles to the door. Included in this set are:

- Metal threaded insert prefixed in rear of each handle
- 1 x screw

Safety

- Always follow the manufacturer's safety instructions when using power tools and adhesives
- Wear safety glasses throughout the installation

Step 1: Set up

You will need

- 4-12mm drill depending upon the size of the fitting
- Safety glasses
- Small Allen key
- Handle and screw

Step 2: Prepare the door

- a) Locate and mark the position for the handles on the door
- b) Drill 4-12mm hole through door at the point marked out above

Step 3: Install

- a) Insert the screw through the predrilled hole in the door from the rear side.
- b) On the other side of the door wind the handle onto the screw. Tighten with the Allen key until secure, taking care not to over tighten.



All Done!